

Must be applied to a clean, dry surface.

- 1.** Place the graphic into position and verify measurements.
- 2.** Turn graphic over and peel back several inches of the liner and then crease it.
- 3.** Turn the graphic back over and tack it into position with light pressure.
- 4.** Using a plastic squeegee, press the graphic in place as you remove the liner. Work from the center to the edges.
- 5.** Use overlapping strokes and work slowly to avoid trapping air bubbles under the graphic.
- 6.** When the graphic is in place, squeegee all edges again to ensure a strong bond with the surface.

