

Tools needed: Masking tape, Tape measure, Squeegee, Glass cleaner, Spray bottle with water, Paper towels

- 1.** Clean the window and allow to dry. Clings are best installed when outside temperature is over 65° F.
- 2.** Measure your window area to determine exactly where you will place the cling.
- 3.** Leave the backing on the cling and tape it to the window at the top with masking tape.
- 4.** Lift the graphic off the window at the bottom and slowly remove the backing from the top of the cling.
- 5.** Spray the window area with water before removing the backing 6" at a time.
- 6.** Squeegee from top to bottom as you slowly remove the backing.
- 7.** Once graphic is applied, squeegee from center to edges to remove air bubbles.
- 8.** Remove masking tape and squeegee the top of the graphic.
- 9.** Wipe up any excess moisture with paper towels.

